
RedBeam Mini LED Light

Installing Batteries

The RedBeam Mini LED Light is powered by three LR-44 (or AG13) button cell batteries (included). Replacement batteries are commonly available in camera shops and drug stores.

To install (or replace) the batteries, unscrew the end cap that the key chain is attached to. Insert three fresh batteries, each with positive (+) side up (see Figure 1). Upon screwing the end cap back on the light, battery installation is complete.




Figure 1. The positive (+) side of all three batteries should face the key chain end (or back) of the light, and the negative (-) side of the batteries should face the LED end (or front) of the light.